




FreshDate 3 – Updating Data File

Please follow the steps below to update the data file on your FreshDate 3 printer.

1. Plug your USB drive into your printer.
2. Log in as Admin. The default password is 1234.




3. Go to Prep.








4. Click on the printer icon on the left-side toolbar.



5. Click on the arrow on the top-left to cycle through the tabs until you see “Printer Update”.





6. Click on “Printer Update” and select the data file.





7. Click on your data file. Wait for the file to load.

NOTE: If you get the message, “No USB drives connected”, you need to format your USB drive. Please click [here](#) for directions.



8. You will be redirected to your main label screen with the updated labels. Before you start printing, please restart your printer by pressing and holding the power button.

