





1. On your FreshDate 3, log in as an Admin. The default password is 1234.



2. Click on Edit.




3. Click on the item you want to change the price for.






4. In Button Properties, scroll down until you see Label Data -> Price.



5. Type in the new price. Click Done.



6. Repeat these steps for all labels that need price updates. Once updates are completed, click on the menu on the top-right corner to go back to Prep and print.